

SECTION 13

SYNC NON-SYNC DESK PANEL PA8/513




Fig. 13.1 Circuit of the PA8/513

The PA8/513 carries eight *Sync/Auto/Non-sync* keys; inputs and outputs are both d.c. signals. Each key controls, via a control panel¹, sync-selection and interlock circuits in the associated channel of a video mixer². The circuit of the PA8/513 is given in Fig. 13.1.

References to Typical Associated Equipment

1. Group Mixer Control Panel PA6/510.
2. Studio Video Mixing Equipment EP5/502, Instruction V.15.

TES 1/67